DR.MERCOLA®



Owner's Manual

Welcome

Thank you for purchasing Dr. Mercola's Clear*Air* Tabletop Air Purifier. This air purifier has been designed to provide you a cleaner living space with low maintenance operation. Please read through the usage and service instructions outlined in this owner's manual.


Packaged Materials

- 1 ClearAir Tabletop Air Purifier (with Filter pre-installed)
- 1 Power Cord
- 1 Replacement Filter
- 1 Owner's Manual

Table of Contents

Welcome
Packaged Materials2
Diagrams3
Cautions & Warnings3
Product Specifications
Getting Started
Settings5
Light
Cleaning & Maintenance6
Filter Replacement
Warranty Information

Diagrams



Cautions & Warnings



Do not operate this unit unless it is completely assembled.



Do not block the ventilation or filter.



Do not use Away Mode in a space occupied by people or pets. Short term exposure to ozone levels exceeding 0.5 ppm can cause temporary adverse reactions.



Do not operate this unit near heat source, open flame or flammable/ combustible fluids.



Do not allow unit to come in contact with water.



This unit is not intended for outdoor use.

Product Specifications

Input Voltage
Output Voltage
Power Consumption
Unit Dimensions
Unit Weight
Activated Oxygen Output
Effective Area up to 850 ft 2
Warranty 1 Year Manufacturer's Warranty

Getting Started

- Begin by removing the ClearAir Tabletop Air Purifier and Power Adapter from the packaging.
- Locate a suitable location to place your unit. For best results, place your unit in an area with good circulation on an elevated surface like a table, counter or shelf. Never place an operating unit on the floor.
- 3. Plug the Power Adapter into the Power Port of your unit and then plug the Power Cord Plug into a wall outlet.
- Press the Power Button once to turn your unit ON which begins in Ionization Mode, signaled by a green light. Press it again to change to Purification Mode, signaled by a blue light. Press it one more time to turn the unit OFF.
 - **NOTE:** Once your unit is turned OFF, it will continue to operate for 30 seconds to clear any ozone remaining inside.
- 5. Press the Away Mode Button located underneath the Power Button to activate the Away Mode, signaled by a red light.
 - **NOTE:** When Away Mode is selected, your unit will revert back to its previous mode after the 30 minute cleaning cycle has ended. Away Mode can also be activated while the unit is OFF. Once complete, your unit will shut OFF.

Settings

IONIZATION MODE (Green Light):

Ionization Mode is your unit's default mode. This mode utilizes Ionization, which charges the particulates in the air until they clump together and fall out of your breathing space, and a carbon filter for removing airborne particulates such as smoke, pollen, and pet dander.

PURIFIER MODE (Blue Light):

In addition to the benefits of Ionization, PURIFIER Mode creates safe levels of Activated Oxygen (O₃), which breaks down bacteria, viruses, mold, and mildew in the air and on surfaces.

AWAY MODE (Red Light):

High Power Purification Mode creates Activated Oxygen (O₃) and Ionization for a powerful 30 minute cleaning cycle before reverting back to the previous mode setting.

NOTE: Activated Oxygen can cause temporary respiratory and eye irritation. Keep room unoccupied when using Away Mode.

Light

The internal light can be turned ON/OFF by pressing the touch-sensitive Light Button on the top panel.

NOTE: The light will activate for 3 seconds when changing Modes with the light OFF to notify you of which mode is active.

Cleaning & Maintenance

NOTE: For proper operation, the unit should be cleaned at least once per month. The filter should be replaced at least once per year, but is dependent on the level of pollutants in the room the unit is placed in.

WARNING: No part of this unit should come into contact with water during cleaning.

- 1. Turn the ClearAir Tabletop Air Purifier OFF and remove the *Power Plug*.
- Unscrew the Filter Screw to remove the Filter Cover, and carefully remove the Filter from the unit.
- Using compressed air or the hose attachment of a vacuum cleaner, blow and/or vacuum the Filter to remove dust or debris. After one year of use, the Filter should be replaced.
- Blow the interior of your unit out with compressed air, or vacuum using the hose attachment of a vacuum cleaner.
- 5. Replace the *Filter*, *Filter Cover*, and *Filter Cover Screw*.





Correct Side Out

Wrong Side Out

- 6. Dust exterior of unit with dry duster or cloth.
- 7. Plug your unit in and return it to your previously set mode.

If your unit has stopped working properly, refer to your Warranty Information (Page 7) for coverage and replacement instructions.

Filter Replacement

Filter life depends upon the level of pollutants in the space being cleaned. The filter in your ClearAir Tabletop Air Purifier should be replaced at least once per year to ensure the highest quality of purification. One Replacement Filter is included with the ClearAir Tabletop Air Purifier. To order additional Replacement Filters, please visit **www.shop.mercola.com** or contact Mercola Customer Service at **(877) 985-2696**.

Warranty Information

1 YEAR LIMITED WARRANTY

Dr. Mercola's ClearAir Tabletop Air Purifier is warranted to be free from all defects in material and workmanship in normal household use for a period of 1 year from date of purchase. The warranty is granted only to the original purchaser. The warranty is subject to the following provisions. The warranty does not cover normal wear and tear. Any damages or malfunctions caused by negligence, abuse, improper use or use not in accordance with the Owner's Manual are not covered by this warranty. If the unit is dropped, damaged, immersed in or splashed with liquids, these are not covered by this warranty. Likewise, defects or damages caused by unauthorized service or alterations are not covered. Using this unit for commercial purposes voids this warranty. Natural Health Partners, LLC will at its option, repair or replace a defective part on the ClearAir Tabletop Air Purifier that is covered by this warranty. As a matter of warranty policy, Natural Health Partners, LLC will not refund the customer's purchase price. To obtain warranty service you must return the defective Tabletop Air Purifier along with proof of purchase to Natural Health Partners, LLC. All delivery charges on parts or units submitted under this warranty shall be borne by purchaser. Unless this warranty is expressly renewed or extended by Natural Health Partners, LLC any repaired or replaced part of the unit shall be warranted to the original purchaser only for the length of the unexpired portion of the original warranty.

FURTHER LIMITATIONS AND EXCLUSIONS ARE AS FOLLOWS: Any warranty that may be implied in connection with your purchase or use of the Dr. Mercola's ClearAir Tabletop Air Purifier including any warranty of merchantability is limited to the duration of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above warranty may not apply to you. Your relief for the breach of this warranty is limited to the relief expressly provided above. In no event shall Natural Health Partners, LLC be liable for any consequential or incidental damages you may incur in connection with your purchase or use of the Dr. Mercola's ClearAir Tabletop Air Purifier. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

DR. MERCOLA®

DISTRIBUTED BY: NHP 125 SW 3rd Place Cape Coral, FL 33991 USA (877) 985-2696 Made in China 20314-v101